

Triple Wheelie Bin Storage Assembly Instructions

Before you commence the assembly process, we recommend that you read these instructions thoroughly beforehand to familiarize yourself with the assembly process and to also check that you have the correct components. If for any reason you need assistance, you can find our contact details on the top of page of these instructions.

We highly recommend that any assembly is carried out on a flat, level surface if possible and that you use another person to assist you if necessary for your convenience all guide holes are pre-drilled.

You can check our **YouTube channel** for assembly video.

[Please click here](#)

Package contents:

- 3x Back panel
- 3x Doors
- 2x Side panels
- 3x Roof
- 3x Metal bards
- 1x Back bar
- 1x Front bar
- 2x Spacer blocks
- 1x Spacer bar
- 2x Middle Section divider
- 60mm screws
- 85mm Screws
- 32mm Black screws

Tools required:

Electric screwdriver with No2 Pozidrive bit or No2 Pozidrive screwdriver



Step 1



Stand the left-hand end panel upright on a flat, level surface.

Step 2



Arrange the 2 spacer blocks on the ground, adjacent to the end panel, as shown in the photo above. Using the 65mm screws provided, attach the batten on the back panel to the post of the end panel, ensuring that the batten remains vertically aligned to the post fixing.

Step 3



Now secure the right-side panel in place with 65mm screws in the same manner as you attached the left side panel. Repeat steps 1-3 to complete the rest of the wheelie bin slots.

Step 4



After attaching the last right-side panel, your assembly should look like the one in the picture.

Step 5



Now take the front bar and secure it with the 60mm screws as shown in the picture. Please don't forget to use the space bar (70cm) between the posts to ensure that the gap is correct.

Step 6



Carefully lay the assembly on its back and position the metal bar as shown across the bottom of the front posts. Use spacing block (70cm) on both slots as shown to ensure the gap is the right size.

Step 7



Place the roof batten section onto the store and align with the edges of the posts. Secure with provided 85mm screws.

Step 8



Place the roofs sections onto the store and align to the rear batten. **Please note: One lid out of three is smaller. Make sure it is fixed on a middle section.**

Step 9



Secure the roofs to the rear batten with the provided black screws.

Step 10



Arrange the two spacer blocks on the ground, adjacent to the end front, as shown in the photo.

Step 11



Use black screws to secure the doors.

Step 12



Fit the hook to the opposite side of the doors from the hinges to whichever height is the best for you with 2x black screws. Don't forget to attach the provided batten to the other side of the doors while screwing in the black screws to hide the pointy screw end's sticking out of doors.

Step 13



To fit the latch keeper plate, shut the door and hold the latch in the horizontal position. Now fit the keeper and mark its correct fixing position on the post using a pencil or bradawl before securing it in place using the screws provided.

Step 14



If you bought version with shelf – place shelf at your required height and secure it with the provided screws.

Your Triple Wheelie Bin Store is now completed!

We hope that you found your product quick and easy to assemble but if not and you require further assistance or have any questions you can contact us via details above.

Also, you can check our **YouTube channel** for assemble videos, click on the link below:

<https://www.youtube.com/watch?v=u8NKqZ8Qvk4&t=236s>

Or

Type in YouTube search box Arbor Garden Solutions.