

Victoria picnic table and bench set

Before you commence the assembly process, we recommend that you read these instructions thoroughly beforehand to familiarise yourself with the assembly process and to also check that you have the correct components. If for any reason you need assistance, you can find our contact details at the top of the page of these instructions.

We highly recommend that any assembly is carried out on a flat, level surface if possible and that you use another person to assist you if necessary.

You can check our [YouTube channel](#) for assembled videos.

[Please click here](#)

Package contents

1x Tabletop

2x Seats

2x Table A-frames

4x Bench A-frames

6x Braces for the table and benches

***3ft/4ft Compact Version 2x rectangular braces
for the benches and 2x for the table**

70mm coach

Blackcaps


Tools required

10mm socket head

Spanner or battery-operated drill




Step 1




Lay the tabletop upside down on a clean, flat surface taking care not to damage it. Now line up one of the table A-frames centrally on the tabletop as shown in step 2

Step 2




Place one of the table A-frames centrally against the fixing batten ensuring that the gap at the table edge is the same on both sides. Now, using 2 of the supplied coach screws and the predrilled holes, secure the table A-frame to the fixing batten on the tabletop.

Step 3




Place a longer cross brace in position as shown, ensuring that it is flush with the underside of the table A-frame it to the A-frame with a coach screw and proceed to step 4

Step 4




Ensure that the brace is lined up centrally on the table and attach

Step 5




Lay one of the bench seats face down on the flat surface as you did with the tabletop.

Step 6




Place one of the bench A-frames centrally against the fixing batten ensuring that the gap at the bench edge is the same on both sides. Now, using 2 of the supplied coach screws and the predrilled holes, secure the bench A-frame to the fixing batten on the seat and repeat for the remaining 3 A-frames.

Step 7




For a 3ft or 4ft set, take one of the bench braces (rectangular) and align it between the two A-frames

Step 8




Secure into place using 2 coach screws at either end as shown.

Step 9




Add the remaining braces to both seat assemblies.

Step 10




Finally, turn all completed pieces' right way up and cover any exposed coach screw heads with the cover caps provided. Your Victoria picnic table and bench set are now complete.

Step 11



For a 5ft to 8ft set, place a shorter brace aligned centrally on the seat as shown and affix to the bench with a coach screw.

Step 12



Ensure that the brace is lined up centrally on the bench and attach it to the A-frame with a coach screw.

Your picnic table and bench set are now completed!

We hope that you found your product quick and easy to assemble but if not and you require further assistance or have any questions you can contact us via the details above.

Also, you can check our [YouTube channel](#) for assembled videos, click on the link below:

<https://youtu.be/cf4JKaqxMB0> Or

Type in the YouTube search box Arbor Garden Solutions.