

Generic build instructions – Triple Bay log store

Before you commence the assembly process, we recommend that you read these instructions thoroughly beforehand to familiarise yourself with the assembly process and to also check that you have the correct components.

We highly recommend that any assembly is carried out on a flat, level surface if possible and that you use another person to assist you if necessary.

You can check our **YouTube channel** for assemble video, click on the link below:

[Triple bay wooden log store - assembly video](#)

Package contents

3 x Doors (if with doors)
2 x End panels
3 x Back panels
1 x Base
1 x Lattice
1 x Roof
4 x Centre Posts
65mm Screws
8 x 85mm Screws (For the Base only)
2 x Spacer Blocks

Tools required

Electric screwdriver (No.2 Pozi bit) or
Screwdriver



Step 1

Stand the left-hand end panel (**or right hand for the reversed roof version**) upright on a flat, level surface.

Step 2

Arrange the 2 spacer blocks on the ground (the orientation is not critical), adjacent to the end panel as shown in the photo above. Now place a back panel on the blocks, at 90° to the end panel, aligning the 2 panels ready for fixing.

Step 3

Using the 65mm screws provided, attach the batten on the back panel to the post of the end panel, ensuring that the batten remains vertically aligned to the post.

Step 4

Align one of the longer posts (shorter for a reversed roof) with the other end of the back panel.

Step 5**Step 6**



Attach the panel to the post by screwing through the batten using 65mm screws as before.



Rearrange the spacer blocks and offer up the next panel, aligning and attaching it as before.

Step 7



Repeat step 6 so that all 3 back panels are now attached.

Step 8



Remove the blocks from beneath the 3rd panel and then slide the base into position as shown.

Step 9

Step 10



Attach the base to the end panel front post first, using 1 of the 85mm screw and then secure the rear post in the same way.



Now attach the base to the end panel rear post using one more 85mm screws

Step 11



Using more of the 85mm screws now attach the base to the rear posts as shown.

Step 12



Slide the remaining end panel into place as shown above and attach it to the frame as you did with the first end panel with 85mm screws into the front and rear posts. If you are fitting a kindling shelf, omit steps 13 -15 and attach the front posts before fitting the kindling shelf, lattice and then attaching the roof.

Step 13

Step 14



Carefully place the roof on top of the end panel posts ensuring that the batten ends sit flush with the posts as shown. Now attach the roof to each end panel post with 65mm screws.



Secure the rear of the roof using 65mm screws as shown.

Step 15



Sit the lattice in the store so that it is leaning against the back panel as shown above, so that you have enough clearance to attach the front posts as shown in the next step.

Step 16



Fit a central post into the slotted roof position. By measuring the distance from the side panel to the central post and making sure it is equal at the bottom and the top. (**The space from the side panel to the central post must be equal to the back panels measurements**).

Step 17



Make sure that the centre post sits flush with the roofs batten ends and secure in place with 1 of the 65mm screws.

Step 18



After making sure that the gap at the bottom is the same as in the top attach the centre post to the base panel with the provided 1x 80mm screw.

Step 19



Your Redwood log store is now complete. If you are fitting doors, please proceed with step 20 hinge to the post.

Step 20



Place a spacer block at the front of the log store adjacent to the front-end post and rest the hinge side of the appropriate door on the block, aligning it vertically and horizontally for a good fit. Now use four of the supplied black hinge screws to affix the hinge to the post.

Step 21




Align the top hinge in place, ensuring that the gap between the door and post is consistent at top and bottom.

Step 22



Secure the top hinge in place using more of the black hinge screws. Repeat steps 20 - 22 for any further doors as required.

Step 23



Fit the hook to the opposite side of the doors from the hinges to whichever height is the best for you with 2x black screws. Don't forget to attach the provided batten to the other side of the doors while screwing in the black screws to hide the pointy screw end's sticking out of the doors.

Step 24



To fit the latch keeper plate, shut the door and hold the latch in the horizontal position. Now fit the keeper and mark its correct fixing position on the post using a pencil or bradawl before securing it in place using the screws provided.



Your triple bay log store is now completed!

We hope that you found your product quick and easy to assemble but if not and you require further assistance or have any questions you can contact us via details above.

Also, you can check our **YouTube channel** for assemble videos, click on the link below:

<https://www.youtube.com/channel/UC3b2MzAv6fTkCPnC3QF7V9w>

Or type in YouTube search box Arbor Garden Solutions.